

SET DEVICE HANDING

This Surface Vertical Rod device is pre-set for LHR door use, if the device is installed on RHR door, the following adjustment should be done before installation(see Fig. B).

Install on LRH door shown

The device handing controller A is pre-set at this direction by factory.




Fig. A




Fig. B

Install on RHR door shown

1. Turn the direction of the **device handing controller A** as shown.
2. The **holding screw B** is set on lower position.
3. Change **setting screws C** to upper site.